



**TITAN<sup>®</sup>**  
**CONTROLS**

# FLO-N-BREW™

Xtreme Tea Brewer Item # 702800

## Easy Guide



Sunlight Supply, Inc.

National Garden Wholesale.

VANCOUVER, WASHINGTON U.S.A.



### INSTRUCTIONS – REV. A

**IMPORTANT! Organize the parts and verify that all parts have been included in box before proceeding:**

- (1) 4 gallon 'Brewer' blue bucket with grommet
- (1) Black lid for 'Brewer' bucket
- (1) EcoPlus water pump
- (1) EcoPlus air pump
- (2) Two foot pieces of clear 3/16" air hose
- (1) Adjustable bell fountain kit – 4 pieces
- (1) Black tea dispenser spout
- (2) Air stones
- (2) Xtreme Tea Brew sachets and activators

#### Step 1

##### Building your Flo-N-Brew™ Xtreme tea brewer

- Check to see that your Flo-N-Brew™ Xtreme is clean and free of debris.
- Attach bell fountain head to water pump output port.
- Place water pump (with adjustable bell fountain head attached) into bottom of brewer bucket.
- Attach both pieces of 3/16" clear air hose to the air pump.
- Push both pieces of 3/16" clear air hose through grommets in black lid so they are inside of brewer bucket.
- Attach air stones to each piece of 3/16" clear air hose inside the brew bucket.
- Place air stones in bottom of brewer bucket on either side of the water pump.
- Add fresh (non-chlorinated) water to the brewer bucket.
- Note: Water temperature should be between 60°F and 70°F for best results.
- Plug in water pump to 120 Volt power source – Now your fountain should be working.
- Plug in air pump to 120 Volt power source – Now you should have tons of bubbles in your brewer bucket.

#### Step 2

##### Using your Flo-N-Brew™ compost tea brewer

Now it's time to add your compost tea materials!

##### Directions for using XTREME GARDENING - Xtreme Tea Brews

- Add 1 Xtreme Tea Brew (sachet) and 1 pack of Xtreme Brew Activator (tear and pour) with every 3 gallons of water into Flo-N-Brew™ Xtreme Tea Brewer.
- Brewing times based on ambient air temperature:
- 60° or warmer water = 24 hours for compost tea
- 59° or colder water = 48 hours for compost tea

#### Step 3

##### Applying Xtreme Tea

You've finished brewing and now it's time to apply your Xtreme Tea!

In Ground Plants and Raised Beds:

- Apply 2 to 3 cups of brewed Xtreme Tea as a root drench around the base of established plants, once a week, throughout all stages of plant growth. Xtreme Tea does not need to be diluted, simply follow with irrigation as normal.

Potted Plants:

- Apply brewed Xtreme Tea weekly as a root drench around the base of each plant
- 1-7 gallon pots – Apply 2 cups ( 1 pint)
- 8-15 gallon pots – Apply 4 cups ( 1 quart)
- 16-30 gallon pots – Apply 8 cups (1/2 gallon)
- 31-50 gallon pots – Apply 1.5 gallons
- 51-100 gallon pots – Apply 3 gallons
- 200+ gallon pots – Apply 6 gallons

Reservoirs:

- Keep well aerated
- Add 1 cup of brewed Xtreme Tea per gallon of water. Apply weekly for best results!

Xtreme Results:

- Apply 2 cups (1 pint) of brewed Xtreme Tea per cubic foot of soil to the base of established plants one time per week. For Xtreme results, use in combination with XTREME GARDENING products: Mykos, Azos & CalCarb for exceptionally healthy and robust plants.

#### Step 4

##### Cleaning your Xtreme Tea brewer

- Run Flo-N-Brew™ Xtreme Tea brewer with 2 gallons of hot water and ¼ teaspoon anti-bacterial soap for five (5) minutes and then drain completely.
- Run again with 2 gallons of plain hot water without soap for ten (10) minutes
- Run completely through system and wipe dry with a clean towel.

\*\*\* VERY IMPORTANT\*\*\*

Rinse and fully clean Flo-N-Brew™ Xtreme Tea brewer between every use.



**TITAN<sup>®</sup>**  
**CONTROLS**

www.titancontrols.net

For technical assistance call us at  
1-888-80-Titan or 1-888-808-4826.